

## What can you use Feem Active Cleaner for?

It's very simple. To clean, degrease and remove stains from ALL surfaces. The only thing Feem Active Cleaner doesn't do is remove calcium stains.

## Don't worry.

Feem Active Cleaner may come into contact with food, contains no perfume, no dyes and it's not aggressive on your skin.

## Pay attention!

Leave it to soak long enough to do it's work. Because of this the result will be better and therefore the treatment won't have to be repeated. Do not allow it to dry and do not use it undiluted on unglazed surfaces. Always spray on surfaces from bottom to top.

## Do you always have to use Feem Active Cleaner without diluting it?

To remove stubborn dirt you can best use Feem Active Cleaner in it's pure form. For this you can use our handy 500ml spray bottle. Spray it on the materials that need to be cleaned, leave it for a while and rinse it thoroughly with water.

But it's also possible to add the product to a bucket with water. The ideal mix for a thorough cleaning of large heavily soiled surfaces would be one part of Feem Active Cleaner to 10 parts of water. Keep in mind that you should always rinse thoroughly to avoid residue when using this mixture with water.

For general maintenance, all you need is 15 ml of Feem Active Cleaner to a bucket of 5 litres of water. 15 ml corresponds to about 10 squirts or two caps of our 1 litre bottle. With this dilution you don't need to rinse.

If you want to use it like an instant cleaner? Spray and wipe it dry without rinsing. Ideal for fast cleaning of windows, mirrors, countertops and tables. Fill a spray bottle with a dilution of 25 ml Feem Active Cleaner and 500 ml of water.

## SPECIAL APPLICATIONS

Fryer (inside)	<ol style="list-style-type: none"> <li>1. Fill the fryer to just below the brim with a mixture of 250 ml of Feem Active Cleaner and warm water.</li> <li>2. Heat the liquid to about 100 °C (don't let it boil).</li> <li>3. Leave it for about 20 minutes.</li> <li>4. Rub persistent and burnt edges with a sponge.</li> <li>5. Rinse thoroughly with water.</li> </ol>
Thorough cleaning of ovens	<ol style="list-style-type: none"> <li>1. Spray oven completely with Feem Active Cleaner.</li> <li>2. Fill a refractory dish with a mixture of 250 ml Feem Active Cleaner and warm water.</li> <li>3. Set the oven at 200 to 250 °C.</li> <li>4. Let the mix evaporate (vapour will nestle between the dirt and the furnace wall).</li> <li>5. Remove stubborn grease and dirt with a sponge.</li> <li>6. Rinse with water.</li> </ol>
Cleaning and degreasing kitchen filters	<ol style="list-style-type: none"> <li>1. To give the filter a thorough internal cleansing, it's recommended to spray the filter with plenty of Feem Active Cleaner.</li> <li>2. Leave it to soak for about 30 minutes.</li> <li>3. Rinse thoroughly with warm water.</li> </ol>
Removing wallpaper	<ol style="list-style-type: none"> <li>1. Add 50ml of Feem Active Cleaner per litre of hot water.</li> <li>2. Use this mixture to thoroughly wet the wallpaper with a sponge or a pressure sprayer.</li> <li>3. Let it soak for about 10 minutes before removing the paper.</li> </ol>
Removing stains from textiles (carpets, tablecloths, clothes, ...) and cleaning white sports shoes and sneakers, ...	<ol style="list-style-type: none"> <li>1. Check beforehand that the fabric preserves it's colour.</li> <li>2. Spray Feem Active Cleaner on the stain.</li> <li>3. Let Feem work for at least 5 minutes.</li> <li>4. Use a damp cloth or rinse after-treatment to prevent discolouring on the edges of the treated spot (circles).</li> <li>5. Afterwards you can wash the clothing and/or the fabrics in your washing machine with ordinary washing powder.</li> </ol>

## GENERAL USAGE

All types of flooring	Car interior	Extractor	Greenhouses	Lipstick	Pots & pans	Sports equipment
Animal baskets	Car rims	Faucets	Grilling	Mascara	Radiators	Stoves
Basins	Caravan	Filters	Highlighter	Microwave ovens	Refrigerators	Terraces
Bath	Carpets	Fireplaces	Household appliances	Mirrors	Resin	Textiles
Bathroom tiles	Ceramic cooker	Fly droppings	Ink	Mobile homes	Sauce stains	Tools
BBQ	Clothes	Fruit stains	Insects	Motorcycles	Sculptures	Toys
Bibs	Coffee stains	Fryer	Ketchup	Mud	Shirt collars	Trailer
Bicycle	Coffee machines	Furniture	Kitchen appliances	Nicotine	Shoe stripes	Trainers
Bicycle chain	Crayons	Garden furniture	Kitchen cabinets	Number plates	Shoeshine	Ventilation filters
Boats	Crystal chandeliers	Gourmet set	Kitchen counter	Oil	Showers	Verdigris
Canvas	Doors	Grass stains	Lawn mower	Ovens	Sneakers	Windows
Car	Engines	Gravestones	Leftovers	Permanent marker	Soot	...